

Affordable Reliable Service

ABN 27 106 103 315

www.aggdoors.com.au enquiries@aggdoors.com.au (03) 8789 1342



ELSEMA FMT-301

Coding your Remote to the Opener

- 1. Take off the cover of your existing remote (if no remote then you will need to take the cover off the opener to see the control panel).
- 2. Take the cover off the new remote.
- 3. Match the dipswitch code like for like if you have an existing Elsema KEY-301. If you do not have an existing KEY-301, match the code mirror image.
- 4. Test remote to see if it works.







