



Affordable Reliable Service

ABN 27 106 103 315

www.aggdoors.com.au

enquiries@aggdoors.com.au

(03) 8789 1342



Genuine C840

Programming your Keypad into the Opener

1. Locate the learn button on the opener
2. Press and release the learn button. The LED will light.
3. Enter a 4 digit PIN of your choice
4. Press and hold the Enter button until the light bulb blinks once or 2 clicks are heard.

