



Affordable Reliable Service

ABN 27 106 103 315

www.aggdoors.com.au

enquiries@aggdoors.com.au

(03) 8789 1342



*Genuine Forza 1200 /
Boss HT20*

Saving or Adding remote transmitter

1. Press the S button until "0" appears.
2. Release the S button
3. Press the button of the transmitter to be memorized.
4. The "0" on the display disappears, the transmitter has been saved.
5. For each transmitter (maximum 20) repeat the procedure for each single transmitter.

BUZZER SIGNAL	MEANING
1 beep	code memorized
2 beeps	code already memorised
3 beeps	memory full

Deletion of all transmitters

1. Switch off the 240 Vac power supply.
2. Press and hold the S button.
3. Switch on the 240 Vac power supply while holding the S button for 5 seconds until you hear the 2 beeps from the control unit.

