



Affordable Reliable Service

ABN 27 106 103 315

www.aggdoors.com.au

enquiries@aggdoors.com.au

(03) 8789 1342



ECA REMOTES

Coding in Your Remotes to the Opener

Method 1

1. Take the operational remote control of the unit and stand about 2m' from the receiver. Press and hold both the buttons (III) and (I) simultaneously for 5 seconds (If this does not work, please hold buttons (I) and (II) instead).
2. After releasing the buttons of the original remote control, the LED light in the receiver will turn on.
Indicating that the receiver is ready to learn the new remote control's button.
3. Choose, press and hold the one of the buttons on the NEW remote control for 5 seconds and then release. The LED light will turn off to indicate that the remote control's button has been learned into the receiver's memory.



Affordable Reliable Service

ABN 27 106 103 315

www.aggdoors.com.au

enquiries@aggdoors.com.au

(03) 8789 1342

1. Remove the jumper "Clear" in the receiver and the LED light will turn on.
2. Choose, press and release the button on the new remote control, which you would like to operate the receiver, for a period of five second.
3. Return the "Clear" jumper to its place.
4. Repeat steps 1-4 for teaching more remote controls.

