



**Affordable Reliable Service**

ABN 27 106 103 315

[www.aggdoors.com.au](http://www.aggdoors.com.au)

[enquiries@aggdoors.com.au](mailto:enquiries@aggdoors.com.au)

(03) 8789 1342



*Genuine Tilt-A-Way Remote*

## **Coding your Remote into the Opener**

1. Remove the light cover from the motor.
2. Locate the remote programming button on the motor's circuit board.
3. Press the program button on the motor once and immediately release this button. A red light will illuminate. (if the red light does not illuminate beside the button you have just pushed then this is the wrong button)
4. In less than 5 seconds, push and hold button A or button 1 on the new remote.
5. The red light will go out and remote is coded.

## **Deleting the Codes from your Opener**

1. Press and hold the receiver button for 12 seconds.
2. Test remotes to check that the code has been deleted.

