AGG DOORS
GATES & GARAGE DOORS™
ABN 27 106 103 315
www.aggdoors.com.au
enquiries@aggdoors.com.au
(03) 8789 1342

Active BHT4

Coding your Remote into the Motor

1. Press the Radio Set (for overhead openers) or Learn (for roller door openers) button located on your opener.
2. Push the desired button on your remote control.
3. Test the operation of your new remote.

Clearing the Codes from Your Overhead Opener

1. Hold down the Radio Set Button for 5 seconds.
2. Test your motor to make sure the code has been successfully deleted.

Clearing the Codes from Your Roller Door Opener

1. Turn power to the opener off.
2. Press and hold the learn button.
3. Turn the power back on and continue holding the Radio Set Button for another 10 seconds.
4. Test your remote to make sure the code has been deleted.