



ABN 27 106 103 315

www.aggdoors.com.au

enquiries@aggdoors.com.au


(03) 8789 1342



Genuine C231

Programming of your new keyboard

1. Connect your keyboard to your already-programmed remote control with the supplied clip (see diagram).
2. Press the button on your new remote control that you use to control your motor. Keep it pressed down.
3. Press the ENTER button on the keyboard. The lighting of the keyboard illuminates. Let the ENTER button go.
4. Type your PIN code (factory setting=1234). Press the ENTER button.
5. The LED light on the keyboard blinks. Let the button on your remote control go.
6. Wait 10 seconds.
7. Your keyboard is programmed.



Attention: If you do not keep the button on your remote control pressed down until step 4, the programming of your keyboard will fail.

