AGG DOORS
GATES & GARAGE DOORS™
ABN 27 106 103 315
www.aggdoors.com.au
enquiries@aggdoors.com.au
(03) 8789 1342

*Genuine D323*

## Programming with the Receiver

**Warning:** Please use this type of programming only if you do not have a functional remote left. This programming method deletes all already programmed remotes.

1. Press and hold the P button on the receiver until the LED 2 flashes.




2. Press several times the button P until LED 7 flashes.



3. Press the button on your new remote until the LED 7 flashes fast.




4. Press the P button and release it. Wait 10 seconds.

5. Your new remote is programmed.