AGG DOORS
GATES & GARAGE DOORS™
ABN 27 106 103 315
www.aggdoors.com.au
enquiries@aggdoors.com.au
(03) 8789 1342

Genuine E840M

Programming Your Keypad Into the Motor

1. Locate the Learn button on the garage door opener.
2. Press and release the Learn button. The LED will light within 30 seconds.
3. Enter a 4-digit personal identification number (PIN) of your choice.
4. Press and hold the ENTER button until the light bulb blinks once or 2 clicks are heard.